




UNICO 7

How to install Vesa mount

HOW TO INSTALL VESA MOUNT

1. Take off Rear Cover


Step 1 → Put on a protection cushion on table
→ Lie down the system unit (Panel faces table)
and to let Stand lie on outside of table.




Screw location (2-place)

Protection cushion

Step 2 → Remove two screws



Step 3 → Rear Cover by sliding as direction as shown



Rear Cover

Step 4 → Take off the Rear Cover




HOW TO INSTALL VESA MOUNT

2. Disassemble VESA bracket

Step 1 → Remove 8 screws

VESA bracket




Step 2 → Remove VESA bracket



HOW TO INSTALL VESA MOUNT


3. Take off Rear Small Cover

Step 1 → Remove 2 screws



Screw locations (2-place)


Step 2 → Remove rear small cover



HOW TO INSTALL VESA MOUNT


4. Take off L Stand

Step 1 → Remove 3 screws



Screw locations (3-place)

Step 2 → Remove L-Stand as direction as shown.




HOW TO INSTALL VESA MOUNT

5. Install VESA Bracket

Step 1 → Locate VESA bracket at rear.




Step 2 → Fix VESA bracket in place with 8 screws.



VESA bracket

HOW TO INSTALL VESA MOUNT

6. Install the Rear Small Cover




Screw locations (2-place)

To install Rear small cover as direction as shown and fix it by 2 screws.

HOW TO INSTALL VESA MOUNT

7. Install the 'No hinge' Cover

Step 1 → To install the No hinge cover by 2 screws





Step 2 → Fix the Nohinge cover on the Rear cover.

HOW TO INSTALL VESA MOUNT

8. Install the Rear Cover

Step 1 → To install the Rear cover as direction as shown.



Step 2 → To fix the Rear cover by 2 screws.

HOW TO INSTALL VESA MOUNT

VESA Completion View

